

# คู่มือการใช้ผลิตภัณฑ์

หม้อเอนกประสงค์

รุ่น AN-PSG1435



# แนะนำสินค้า AN-PSG1435

ปรุงอาหารรสเลิศทุกชนิดโดยไม่ต้องเสียเวลา ผลิตภัณฑ์นี้ผ่านการรับรองมาตรฐาน 3C แห่งชาติ และใช้สารเคลือบตัวกระทะนำเข้า ปลอดภัย ทำความสะอาดง่าย ดีต่อสุขภาพและเป็นมิตรต่อสิ่งแวดล้อม

## คุณสมบัติของเครื่องใช้ไฟฟ้า

- ที่จับฝาหม้อ
- ฝาแก้วใช้ในการครอบ
- หม้อซูบ
- เตาย่างไฟ
- ปุ่มหมุนปรับอุณหภูมิความร้อน
- กระทะปิ้งย่าง

**หมายเหตุ 1:** ผลิตภัณฑ์นี้ใช้งานได้ โดยคุณสามารถเปลี่ยนโหมดหม้อร้อนเป็นโหมดย่างได้

โดยสลับหม้อและวางจานอย่างลงบนฐาน

**หมายเหตุ 2:** ผลิตภัณฑ์นี้ไม่เหมาะที่จะใช้เป็นประจำหรืออาหาร  
เป็นเวลานาน ส่วนประกอบข้างต้น  
และใช้ร่วมกับเครื่องมือของแบรนด์นี้เท่านั้น

## **วิธีการใช้**

1. ก่อนเปิดเครื่อง โปรดตรวจสอบให้แน่ใจว่าไม่มีสิ่งแปลกปลอม  
บนฐานทำความร้อน และด้านล่างของตัวกระทะ แนะนำให้ใช้ผ้า  
เช็ดจาน เช็ดกันกระทะให้สะอาดก่อนใช้ หลังจากวางลงบนตัว  
ฐานทำความร้อนแล้วค่อยๆหมุนตัวกระทะเพื่อให้แน่ใจว่าตัวหม้อ  
สัมผัสกับฐานทำความร้อนร้อนอย่างเหมาะสม

2. เนื่องจากก้นของหม้อมีลักษณะเว้า ดังนั้นการนำความร้อนจะดี  
เยี่ยมก็ต่อเมื่อจุดเว้าของหม้อสัมผัสโดยตรงกับฐานทำความร้อน  
ห้ามนำกระทะออกจากฐานทำความร้อนเป็นเวลานานเพราะความ  
ร้อนจากฐานทำความร้อนจะทำการเผาไหม้โดยเปล่าประโยชน์  
และส่งผลให้ฐานทำความร้อนเกิดความเสียหายได้

3. วางตัวกระทะให้เหมาะสมเพื่อให้แน่ใจว่าสวิตช์นิรภัยนั้นมีสัญญาณไฟติดอยู่
4. วิธีการปรับอุณหภูมิสามารถเลือกอุณหภูมิที่แตกต่างกันได้ตามประเภทอาหารโดยหมุนได้ตามอุณหภูมิที่ต้องการ
5. หลังจากปรุงอาหารเสร็จเรียบร้อยแล้ว ปิดสวิตช์โดยหมุนทวนเข็มนาฬิกา เพื่อให้แน่ใจว่าไฟถูกตัดจากแหล่งกำเนิดแล้ว จึงดึงปลั๊กของสายไฟออก

## **ข้อควรระวัง**

1. แรงดันไฟฟ้าของผลิตภัณฑ์นี้คือ 220V และความถี่ 50Hz เพื่อความมั่นใจก่อนการใช้งาน โปรดอยู่ห่างจากสิ่งของที่ติดไฟ ก่อนทำการแยกชิ้นส่วนหรือประกอบผลิตภัณฑ์ โปรดแน่ใจว่าได้ถอดชิ้นส่วนที่เกี่ยวข้องกับแหล่งจ่ายไฟภายในภาชนะเรียบร้อยแล้ว เพื่อหลีกเลี่ยงอุบัติเหตุที่จะเกิดขึ้น

2. ห้ามมิให้ผลิตภัณฑ์นี้เผาแผ่นความร้อนเปล่าๆ เป็นเวลานาน โดยไม่มีน้ำในกระทะโดยเด็ดขาดและก่อนนำกระทะออกจากฐาน ทำความร้อนโปรดจงมั่นใจว่าไฟฟ้านั้นถูกตัดเรียบร้อยแล้ว และ ห้ามเผาภาชนะใดๆ นอกเหนือจากตัวหม้อและกระทะที่แนบมากับ ผลิตภัณฑ์

3. หากสายไฟเกิดความชำรุดเสียหาย เพื่อหลีกเลี่ยงอันตราย สายไฟนั้นจะต้องได้รับการซ่อมแซมจากผู้ผลิตหรือฝ่ายซ่อมบำรุง โดยผ่านมาตรฐานทางวิชาชีพเท่านั้น

4. ผลิตภัณฑ์นี้ไม่สามารถทำงานในโหมดจับเวลาหรือระบบรีโมท คอนโทรลอิสระได้

5. พื้นผิวของผลิตภัณฑ์จะร้อนขณะใช้งาน ห้ามใช้มือสัมผัสโดยเด็ดขาดในระหว่างการทำงานและในช่วงเสร็จสิ้นการทำงาน เพื่อหลีกเลี่ยงการลวก

6. ไม่สามารถใช้ร่วมกับภาชนะที่ไม่เกี่ยวข้องกัผลิตภัณฑ์นี้ได้ เพื่อหลีกเลี่ยงความเสียหายต่อภาชนะที่ไม่เกี่ยวข้องและความเสียหายต่อฐานทำความร้อน

7. ในระหว่างการทำงานเพื่อหลีกเลี่ยงอุบัติเหตุโปรดอย่าขยับตัว กระจกและอย่าใส่ส่วนผสมที่ไม่เกี่ยวข้องลงในกระจก
8. ก่อนทำความสะอาดต้องถอดปลั๊กไฟและทำความสะอาดพื้นผิวของกระจก โปรดอย่าใช้ผลิตภัณฑ์ที่เป็นโลหะหรือเนื้อแข็งในการ เช็ดทำความสะอาด เพื่อหลีกเลี่ยงการทำลายผิวเคลือบ หลังจาก ทำความสะอาดตัวกระจกแล้วให้เช็ดอีกครั้ง
9. ห้ามจุ่มผลิตภัณฑ์ทั้งหมดลงในน้ำ เพื่อทำความสะอาดโดย เต็ดขาดเพื่อไม่ให้ฐานทำความร้อนเกิดน้ำไหลเข้า ซึ่งจะส่งผลให้ ไฟฟ้าลัดวงจรและก่อให้เกิดอันตราย ถ้ามีน้ำต้องซับให้แห้งก่อน ถึงนำมาใช้งาน
10. เมื่อทำความสะอาดผลิตภัณฑ์ เพื่อป้องกันไม่ให้ผลิตภัณฑ์ เปลี่ยนสีหรือเสียรูปทรง ห้ามใช้สารเคมีทำความสะอาด เช่น แอลกอฮอล์ น้ำมันเบนซิน เป็นต้น
11. ห้ามใช้อุปกรณ์เสริม นอกเหนือจากผลิตภัณฑ์ที่แนบมากับ กล่อง ห้ามถอดประกอบหรือดัดแปลงผลิตภัณฑ์นี้ด้วยตัวเองโดย เต็ดขาด เพื่อหลีกเลี่ยงความเสียหาย

12. ผลิตภัณฑ์นี้มีระบบป้องกันการไหม้ เมื่ออุณหภูมิสูงเกินไปจะหยุดให้ความร้อนโดยอัตโนมัติ ข้อควรระวังไม่ควรปล่อยให้กระทะแห้งเด็ดขาด

13. เมื่อใช้ผลิตภัณฑ์เป็นครั้งแรกจะมีกลิ่นควันเล็กน้อยซึ่งเกิดจากการใช้งานครั้งแรก กลิ่นจะหายไปหลังจากใช้ไประยะหนึ่งแล้ว

14. ตรวจสอบให้แน่ใจว่าไม่มีสายไฟวางอยู่บนกระทะก่อนเปิดการใช้งาน

15. โปรดอย่าใช้ผลิตภัณฑ์นี้ใกล้วัสดุที่ติดไฟได้ง่าย เช่น ผ้าม่าน หรือตู้เสื้อผ้าเพื่อป้องกันไม่ให้เกิดไฟไหม้

16. ผลิตภัณฑ์นี้ใช้ภายในอาคารเท่านั้น หากเกิดความเสียหายกับผลิตภัณฑ์ โปรดส่งให้แผนกหลังการขายตรวจสอบทันทีและทำการซ่อมแซมเพื่อความปลอดภัย

17. เมื่อทิ้งผลิตภัณฑ์นี้โปรดทำการตัดสายไฟและส่งมอบให้กับแผนกที่เกี่ยวข้องเพื่อการรีไซเคิล

18. สวมถุงมือป้องกันทุกครั้ง เมื่อคุณต้องการเคลื่อนย้ายกระทะอย่าง

# Instruction Manual

Pot and Grill

Model

AN-PSG1435





# Product Introduction AN-PSG1435

Cook all kinds of delicacies without cooking needs.

The product has passed the national 3C certification, and the pan body coating is used. Imported paint-free, easy to clean, less lampblack, healthy and environment-friendly.

## Feature of appliance

1. Pot cover handle.
2. Glass cover.
3. Soup pot (Aluminum Alloy)
4. Base (Aluminum Alloy)
5. Temperature Adjustment and Twisting
6. Grill Plate (Aluminum Alloy)

**Note 1:** This product is functional, you able to change Hot pot mode to be a grill mode by switch the pot and put Grill pan on base.

**Note 2:** This product is not suitable to be used as a container to store food for a long time. The above components are only used in conjunction with the corresponding complete machine of this brand.

## Usage

1. Before turning on the power supply, please ensure that there is no foreign matter between the heating plate of the base and the bottom of the pan body. It is suggested to use dishcloth to wipe the bottom of the pan clean before using it. After putting it on the pan

body, gently rotate the pan body to make sure the pot body is in good position with the heating plate.

2. The bottom of the pan body is concave, and the heat transfer effect will be the best when it is in close contact with the convex heating plate. It is forbidden to place part of the pan body outside the heating plate, otherwise it will cause the heating plate to burn empty and easily lead to damage to the heating plate.
3. Place the pan body well to ensure that the safety switch is on.
4. The temperature adjustment method adopted by the electric heating pot can choose different temperatures according to the different foods and tastes cooked.

5. After cooking, please turn the thermostat switch counterclockwise to off to ensure power is cut off. After the source, pull out the three-core plug of the power cord.

## **Important Safeguards**

1. The input voltage of this product is 220V and the frequency is 50Hz. Please confirm before using it. Product work. Please stay away from inflammable and explosive articles, and the power socket must be grounded. Disassembling and assembling this product. Please be sure to

disconnect the power supply before any parts of the product.

2. It is strictly prohibited for this product to burn the heating plate empty or dry for a long time without water in the pan. Before the pan body leaves the heating plate, the power must be cut off first. It is forbidden to burn any container other than the original pot body on the heating plate. Boil, otherwise the heating plate will be damaged.
3. If the power cord is damaged, in order to avoid danger, it must be fixed by the manufacturer or its maintenance department or similar departments.

4. This product cannot operate in the mode of external timer or independent remote-control system.
5. The surface of the shell will become hot during use. It is strictly prohibited to use hands during work and during a period of time when the work is completed. Touch the surface of the heating plate, shell and pan body to avoid scalding.
6. The container in the pan body of this product cannot be used on other stoves to avoid deformation of the pan body.
7. During the work, in order to avoid injuries to personnel, please do not move the pan body,

and please do not put the ingredients into the pan.

8. Before cleaning, the power supply must be disconnected, the power plug must be unplugged, and the surface of the pan body in contact with food must be cleaned. Soft cloth can be scrubbed, please do not rinse with any metal products or hard articles to avoid damaging the coating. After cleaning the pan body, use it again. Please wipe the outer surface with a rag and then put it on the heating plate to heat.

9. It is strictly prohibited to immerse the whole product or base in water or other liquids for cleaning, so as not to heat the base. Part of the

water inflow, short circuit phenomenon, causing danger. If there is water, it must be dried before it can be heavy.

10. When cleaning this product, in order to prevent the product from discoloration or deformation, chemical agents cannot be used to wipe it. Such as alcohol, gasoline, etc.

11. Do not use accessories and accessories other than this product. It is strictly prohibited to disassemble or modify this product by oneself. Avoid damage.

12. This product has the function of preventing dry burning. When the temperature is too high, it will automatically stop heating and develop



during dry burning. The sound of dripping is normal, but dry burning is strictly prohibited.

13. When using this product for the first time, it will produce a little smoke smell, which will disappear after using it for a while, and then. It will not appear again, please feel free to use it.

14. Ensure that the power cord will not be connected with sharp edges, burn, other prominent sharp objects or surfaces.

15. Please do not use this product under or near combustible materials such as curtains and closets to prevent it from causing Fire.

16. This product is only used indoors. If there is any damage to the product, please send it to the

after-sales department for inspection immediately. Check and repair to ensure safety.

17. When discarding this product, please cut the power cord and hand it over to a department with relevant qualifications for recycling and discarding.

18. Put protecting glove in every time when you need to move grill pan.