

Aconatic

คู่มือการใช้งาน เครื่องปั๊มลมบั้ง รุ่น AN-TT7539

คำแนะนำ

กรุณาศึกษาคู่มืออย่างละเอียด ก่อนทำการติดตั้งและใช้งาน
เก็บคู่มือนี้ไว้ใช้อ้างอิง

คำแนะนำในการใช้งานและการดูแล

คำแนะนำสำหรับผู้ใช้

โปรดปฏิบัติตามคำแนะนำเหล่านี้

ความปลอดภัยที่สำคัญ

เมื่อใช้เครื่องใช้ไฟฟ้าควรปฏิบัติตามข้อควรระวังเพื่อความปลอดภัยขั้นพื้นฐานรวมถึงสิ่งต่อไปนี้

อ่านคำแนะนำทั้งหมด

- ตรวจสอบว่าแรงดันไฟฟ้าที่ระบุไว้บนผลิตภัณฑ์ว่าตรงกับแรงดันไฟฟ้าที่ใช้ภายในบ้านหรือไม่
- เพื่อป้องกันไฟฟ้าช็อตอย่าจุ่มสายไฟหรือส่วนใดส่วนหนึ่งของเครื่องบึ่งลงในน้ำหรือของเหลวอื่น ๆ
- ห้ามใช้ผลิตภัณฑ์นี้ หากปลั๊กไฟหรือตัวเครื่องเกิดชำรุด หากสายไฟชำรุด คุณต้องให้ช่างผู้ชำนาญหรือศูนย์บริการทำการเปลี่ยนเพื่อหลีกเลี่ยงอันตรายที่เกิดขึ้น
- เมื่อใช้งานครั้งแรกเครื่องบึ่งขนมปังอาจจะมีความร้อนเล็กน้อย โปรดรออย่างน้อยสองสามนาทีก่อนใส่ขนมปัง
- โปรดระวังเครื่องบึ่งขนมปังจะมีอุณหภูมิสูงมากโดยเฉพาะบริเวณช่องสำหรับใส่ขนมปัง
- อย่าใช้เครื่องบึ่งขนมปังใกล้วัสดุที่ลุกไหม้ง่าย เช่น ผ้าปูโต๊ะหรือผ้าม่าน
- อย่าปล่อยให้เครื่องบึ่งขนมปังทำงานโดยไม่มีผู้ดูแล
- ห้ามใช้งานเครื่องนี้เพื่อจุดประสงค์อื่นใดนอกเหนือจากที่อธิบายในคู่มือนี้
- ขณะที่ใช้งาน ห้ามวางสายไฟหรือวัตถุอื่นใดเหนือช่องบึ่งขนมปัง
- ห้ามปิดเครื่องขณะที่เครื่องกำลังทำงานอยู่
- วางเครื่องบึ่งขนมปังให้ห่างจากเปลวไฟหรือบริเวณที่ก่อให้เกิดการลุกไหม้
- เก็บเครื่องบึ่งขนมปังให้พ้นมือเด็ก
- อย่าใส่เครื่องใช้ในครัว อาหารขนาดใหญ่หรือกระดาษฟอยล์ลงในเครื่องบึ่งขนมปังเพราะอาจทำให้เกิดไฟไหม้หรือไฟฟ้าช็อตได้
- หากสายไฟชำรุดเพื่อหลีกเลี่ยงอันตรายต้องเปลี่ยนโดยผู้ผลิตหรือผู้ให้บริการด้านเทคนิคที่ได้รับอนุญาตเท่านั้น
- เครื่องใช้ไฟฟ้านี้ไม่ได้มีไว้สำหรับใช้โดยบุคคล (รวมถึงเด็ก) ที่มีความสามารถทางร่างกายประสาทสัมผัสหรือจิตใจลดลงหรือขาดประสบการณ์และความรู้เว้นแต่จะได้รับการดูแลหรือคำแนะนำเกี่ยวกับการใช้เครื่องโดยผู้รับผิดชอบด้านความปลอดภัย เด็กควรได้รับการดูแลเพื่อให้แน่ใจว่าพวกเขาไม่เล่นกับเครื่องใช้ไฟฟ้า
- อย่าสัมผัสพื้นผิวร้อน
- เครื่องใช้ไฟฟ้านี้ไม่มีวัตถุประสงค์ในการใช้งานร่วมกับเครื่องตั้งเวลาภายนอกหรือระบบคอนโทรลแยก

วิธีการใช้งาน

- เสียบปลั๊กเครื่องบึ่งขนมปังเข้ากับแหล่งจ่ายไฟและปรับให้เข้ากับประเภทของการบึ่งที่คุณต้องการ
- ใส่ขนมปังลงในช่องและกดปุ่มสำหรับกดขนมปังลง ปุ่มจะอยู่จนกว่าเวลาที่ตั้งไว้จะหมดลง
- เมื่อบึ่งแล้วตัวตั้งเวลาจะกลับสู่ตำแหน่งเดิม เครื่องบึ่งขนมปังจะ "ปิด" โดยอัตโนมัติ
- กดปุ่ม "ยกเลิก" และนำขนมปังออกหากคุณต้องการหยุดเครื่องบึ่งขนมปัง
- หากปลายขนมปังติดในเครื่องบึ่งขนมปังให้ถอดปลั๊กออกรอให้เย็นแล้วนำขนมปังออก

เคล็ดลับการบึ่ง

- ชั้นขนมปังที่แห้งและบางจะบึ่งได้เร็วกว่าชั้นชั้นหรือชั้นหนา
- หากขนมปังเริ่มมีคราบน้ำมันให้หยุดการบึ่ง

- อย่าอุ่นเครื่องบั้งขนมปังที่ทาขนมปังด้วยเนยหรือสเปรดอื่นๆ

คำแนะนำในการทำความสะดวก

- ตรวจสอบว่าได้ถอดปลั๊กเครื่องบั้งขนมปังก่อนทำความสะอาดห้ามวางไว้ในน้ำหรือของเหลวอื่นๆ
- ก่อนการทำความสะอาดให้ถอดปลั๊กเครื่องบั้งขนมปังและรอให้เครื่องเย็นลงก่อน
- อย่าใส่วัตถุใดๆ นอกเหนือขนมปังลงในเครื่องบั้งขนมปัง
- เช็ดด้านนอกด้วยผ้าแห้งนุ่ม ๆ เมื่อเครื่องบั้งขนมปังเย็น ห้ามใช้น้ำยาขัดโลหะ ให้เปิดถาดรองที่ด้านล่างของเครื่องบั้งขนมปังแล้วบิดเศษขนมปังออก หากใช้เครื่องบั้งขนมปังบ่อยๆ ควรเอาเศษขนมปังที่สะสมไว้ออกอย่างน้อยสัปดาห์ละครั้ง ตรวจสอบให้แน่ใจว่าถาดรองเศษขนมปังปิดสนิทก่อนใช้เครื่องบั้งขนมปังอีกครั้ง
- อย่าพยายามเอาขนมปังที่ติดอยู่ในช่องออกโดยไม่ได้ถอดปลั๊กและตรวจให้แน่ใจเมื่อนำขนมปังออกอย่าให้กลไกภายในเสียหาย

INSTRUCTIONS FOR USE AND CARE

USER INSTRUCTIONS

Please keep these instructions

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

· READ ALL INSTRUCTIONS

- Before switching on, ensure that the voltage on the characteristics plate is the same as in your home.
- To protect against electrical shock, do not immerse the cord, plug or any part of the toaster in water or other liquid.
- Do not operate any appliance with a damaged cord or plug, or in any abnormal state. If the main cord is damaged, it must be replaced by the manufacturer or the nearest service agent or a qualified person.
- First use the toaster for a few minutes without bread. There will be some smoker at first; this is entirely normal.
- The toaster reaches very high temperatures, particularly in the area of the openings for the bread.
- Do not use the toaster close to or under curtains of other inflammable material; the bread may burn.
- Do not leave the toaster operating without supervision.
- Do not use the appliance for other than its intended use.
- Do not place the cord or any other object over the bread openings on the toaster while it is in use.
- Do not cover the toaster while it is in use.
- Keep the toaster away from flames or hot areas.
- Keep the toaster out of reach of children.
- Do not insert utensils, oversize food, or metal foil packages in the toaster as they may cause fire or electric shocks.
- If the cord is damaged, or any examination, or adjustment of the appliances, to avoid hazards; it must be replaced by the manufacturer or by an Authorized Technical Service.
- This appliances is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Do not touch hot surface.
- This appliance is not intended to be operated by means of an external timer or separate remote-control system

OPERATION

- Plug the toaster in and adjust it to the type of toasting you require, with the regulator.
- Put the bread into the openings and press the start control down. It remains down until the bread is toasted.
- Once toasted, the slices appear in the openings and the start control returns to its original position. The toaster switches "OFF" automatically.
- Press the "CANCEL" and automatic eject button if you wish to stop the toaster.
- If the end bread sticks in the toaster, unplug it, wait for it to cool, and remove the bread.

TOASTING TIPS

- Dry and thin slices will toast quicker than moist or thick slices
- If toast starts to smoke, stop the toasting cycle
- Do not heat toaster that has bread applied with butter or other spreads

CLEANING INSTRUCTION

- Ensure that the toaster is unplugged before cleaning it.
- Never place it in the water or any other liquid.
- To clean, **UNPLUG THE TOASTER AND ALLOW TO COOL.**
- Do not insert any object, including bread, in the toaster.
- Wipe outside with soft dry cloth when toaster is cold, never use metal polish.

Open crumb tray at the bottom of the toaster and brush out crumbs. If toaster is used frequently. Accumulated bread crumbs should be removed at least once a week. Make sure the crumb tray is completely closed before using the toaster again.

- Never attempt to remove bread which has jammed in the slots without unplugging the toaster from the electrical outlet first. Be sure, not to damage the internal mechanism or heating elements when removing bread.

ACONATIC

บริษัท ไฮไฟ เอร์เรียนท์ ไทย จำกัด (มหาชน)
HIFI ORIENT THAI PUBLIC COMPANY LIMITED

83/161-162 ซอยงามวงศ์วาน47(ชั้นชุด2) โทร. 0-2954-5281 , 0-2580-6955
แขวงทุ่งสองห้อง เขตหลักสี่ Core Line. 02-591-9444 , 02-589-5115
กรุงเทพมหานคร 10210



หมายเหตุ : บริษัทขอสงวนสิทธิ์ในการเปลี่ยนแปลงรายการของสินค้าและรายละเอียดสินค้าโดยมิต้องแจ้งให้ทราบล่วงหน้า