

# Aconatic

## គ្រឿងការងារ

# LED TV

វេង 43HS701AN  
វេង 43HS800AN

คำแนะนำ

## กรุณากำชับก่อนมีอ่านกระเอียด ก่อนทำการติดตั้งและใช้งานโทรศัพท์ค้นหานี้ เก็บรักษาไว้ใช้อ้างอิง

## คำแนะนำสำหรับความปลอดภัย



สัญลักษณ์การแจ้งเตือนด้วยสายไฟฟ้าร้อนลูกศรภายในสามเหลี่ยมด้านเท่านี้มีวัตถุประมงเพื่อแจ้งให้ผู้ใช้ทราบถึงการมี "แรงดันไฟฟ้าที่อันตราย" ที่ไม่ได้ดีดคนงานภายในกล่องสินค้าซึ่งอาจก่อให้เกิดความเสี่ยงต่อการถูกช็อกไฟฟ้า

### คำเตือน

1. เพื่อลดความเสี่ยงต่อการถูกช็อกไฟฟ้า โปรดอย่าถอดฝา (ด้านหลัง) เมื่อจากไม่มีชั้นส่วนที่ผู้ใช้สามารถซ่อนได้ กรุณาติดต่อบุคลากรที่มีความรู้และความชำนาญในการซ่อมบำรุง
2. เครื่องหมายในสามเหลี่ยมด้านเท่ากันมีวัตถุประมงเพื่อเตือนให้ผู้ใช้ทราบถึงคำแนะนำในการใช้งานและการบำรุงรักษาของผลิตภัณฑ์
3. อย่าดึงดังอุปกรณ์นี้ในพื้นที่ที่ถูกจำกัดหรืออยู่ในอาคาร เช่น ซุ้มหนังสือ หรือพื้นที่คล้ายคลึงกัน และเว้นระยะห่างตามที่กำหนดเพื่อให้อาสาถ่ายเทสะทวาย ไม่ควรมีสิ่งกีดขวาง เช่น หนังสือพิมพ์ ผ้าม่าน เป็นต้น
4. โปรดอ้างอิงข้อมูลในภาคผนวกด้านล่างภายนอกเกี่ยวกับข้อมูลทางไฟฟ้าและความปลอดภัยก่อนติดตั้งหรือใช้งานอุปกรณ์นี้
5. ปลั๊ก/อุปกรณ์เชื่อมต่อปลั๊กไฟ ควรอยู่ในสถานะที่สามารถใช้งานได้เสมอ
6. เพื่อลดความเสี่ยงจากไฟไหม้หรือไฟฟ้ารีดอต อย่าให้อุปกรณ์นี้โคลนไฟหรือความชื้น ห้ามวางอุปกรณ์ไว้โดนน้ำหยด หรือกระเช็น และห้ามวางวัตถุที่มีของเหลว เช่น แจกัน ไว้บนเครื่องมือ
7. แบบเตอร์ (แบบเตอร์หรือชุดแบบเตอร์) จะต้องไม่มีถูกความร้อนมากเกินไป เช่น แสงแดด ไฟ หรือสิ่งที่คล้ายกัน
8. อย่าวางโทรศัพท์ในที่ที่ไม่นั่งคง เครื่องรับโทรศัพท์อาจตกลงมาทำให้ได้รับบาดเจ็บสาหัส โดยการบาดเจ็บหลายอย่างโดยเฉพาะกับเด็กสามารถหลอกเลี้ยงได้โดยใช้มาตรการป้องกันจ่าย เช่น:
  - ใช้ชุดหูฟังแทนหูที่เน้นนาโนไฟฟ้าลดเสียงเครื่องรับโทรศัพท์
  - ใช้ฟอร์นิเจอร์ที่รองรับโทรศัพท์ได้อย่างปลอดภัยเท่านั้น
  - ไม่วางเครื่องรับโทรศัพท์บนไฟฟอร์นิเจอร์ท่องสูง (เช่น ดูห้องนอนบนหนังสือ) โดยไม่มีที่ยึดทั้งไฟฟอร์นิเจอร์และโทรศัพท์
  - ไม่วางเครื่องรับโทรศัพท์บนผ้าหรือวัสดุอื่นที่อาจอยู่ระหว่างหัวใจเครื่องรับโทรศัพท์และไฟฟอร์นิเจอร์
  - ให้ความรู้แก่เด็กเกี่ยวกับอันตรายของการปืนขึ้นไปบนไฟฟอร์นิเจอร์เพื่อเข้าถึงโทรศัพท์หรือควบคุมตัวโทรศัพท์ที่มีถูกเก็บรักษาและตั้งอยู่ การใช้การพิจารณาแบบเดียวกันช่างดี
  - 9. ไม่ควรวางแหล่งกำเนิดปล่อยไฟ เช่น เทียนไฟที่จุดไฟไว้บนอุปกรณ์
  - 10. รักษาระยะห่างอย่างน้อย 5 ซม. รอบขอบทั้งหมดของขอแสดงผลเพื่อการระบายอากาศที่เพียงพอ

## หมายเหตุสำหรับการทิ้งแบบเตอร์

แบบเตอร์ที่ใช้กับผลิตภัณฑ์นี้มีสารเคมีที่เป็นอันตรายต่อสิ่งแวดล้อม เพื่อรักษาของเราสิ่งแวดล้อม ทิ้งแบบเตอร์ที่ใช้แล้วตามกฎหมายหรือระเบียบข้อบังคับในท้องถิ่นของคุณ อย่างทิ้งแบบเตอร์กับขยะทั่วไปในครัวเรือน สำหรับข้อมูลเพิ่มเติมโปรดดูดิตติดต่อหน่วยงานท้องถิ่นหรือร้านค้าปลีกของคุณที่คุณซื้อผลิตภัณฑ์ เครื่องหมายการค้าทั้งหมดเป็นทรัพย์สินของบริษัทที่เกี่ยวข้องและมีสิทธิ์ทั้งหมด

 อุปกรณ์นี้เป็นเครื่องใช้ไฟฟ้าประเภท II หรืออุปกรณ์ส่องชั้น ได้รับการออกแบบในลักษณะที่ไม่ต้องการการเชื่อมต่อกับสายดิน

 เพื่อป้องกันการแพร่กระจายของไฟ เก็บที่ญี่ปุ่นหรือเปลวไฟอื่น ๆ ให้ห่างจากผลิตภัณฑ์ตลอดเวลา

 การกำจัดผลิตภัณฑ์นี้อย่างถูกวิธี เครื่องหมายนี้ระบุว่าไม่ควรทิ้งผลิตภัณฑ์นี้ร่วมกับขยะในครัวเรือนอื่นๆ ที่ส่วนภูมิภาคฯ เพื่อป้องกันอันตรายที่อาจเกิดขึ้นกับสิ่งแวดล้อมหรือสุขภาพของมนุษย์จากการกำจัดของเสียที่ไม่มีการควบคุม ให้รีไซเคิลอย่างมีความรับผิดชอบเพื่อส่งเสริมการนำทรัพยากรวัสดุกลับมาใช้ใหม่อีกครั้ง หากต้องการส่งคืนอุปกรณ์ที่ใช้แล้ว โปรดใช้ระบบส่งคืนและรับสินค้าหรือติดต่อ ร้านค้าปลีกที่ซื้อผลิตภัณฑ์ พากษาสามารถนำผลิตภัณฑ์ไปรีไซเคิลอย่างปลอดภัยต่อสิ่งแวดล้อม

ห้ามวางโทรศัพท์ในที่ที่ไม่มีมั่นคง เครื่องรับโทรศัพท์อาจหล่นมา ทำให้ได้รับบาดเจ็บสาหัสหรือเสียชีวิตได้ การนาดเจ็บหลาของย่าง โดยเฉพาะกับเด็กสามารถหลีกเลี่ยงได้โดยใช้มาตรการป้องกันง่ายๆ เช่น:

- ใช้ตู้หรือแท่นวางที่แน่นหนาโดยเฉพาะกับเด็กสามารถหลีกเลี่ยงได้โดยใช้มาตรการป้องกันง่ายๆ เช่น:
  - ใช้ฟอร์นิเจอร์ที่รองรับโทรศัพท์ได้อย่างปลอดภัยเท่านั้น
  - ไม่วางเครื่องรับโทรศัพท์บนเฟอร์นิเจอร์ที่สูง (เช่น ตู้หรือตู้ห้องสีอ) โดยไม่ได้ชดทั้งเครื่องเรื่อง และเครื่องรับโทรศัพท์บนโซนรูปแบบรับที่เหมาะสม
  - ไม่วางเครื่องรับโทรศัพท์บนโซนที่หัวใจหรือวัสดุอื่นๆ ที่อาจอยู่ระหว่างเครื่องรับโทรศัพท์และเฟอร์นิเจอร์ที่รองรับ
  - ให้ความรู้แก่เด็กเกี่ยวกับอันตรายของการปีนขึ้นไปบนเฟอร์นิเจอร์เพื่อเข้าถึงโทรศัพท์หรือส่วนควบคุม หากเครื่องรับโทรศัพท์ที่มีอยู่ของคุณถูกเก็บไว้ในห้องนอน สำหรับเด็กที่ยังไม่สามารถเดินทางไปห้องน้ำได้

# สารบัญ

## บทที่ 1 : การแนะนำผลิตภัณฑ์

ข้อควรระวัง .....	4
ผลิตภัณฑ์ .....	4
แหล่งจ่ายไฟและปลั๊ก .....	4
สายไฟและสายสัญญาณ .....	4
สภาพแวดล้อม .....	4
ทำความสะอาด .....	4
แนวโน้มวีบันคนั้น .....	4

## บทที่ 2 : การใช้งานทั่วไป

การเปิดเครื่อง .....	5
การปิดเครื่อง .....	5
การเชื่อมต่อเครือข่าย .....	6

## บทที่ 3 : รายละเอียดอื่นๆ

การแก้ไขปัญหา .....	7
การติดต่องานทีวี .....	7

## ข้อควรระวัง

อ่านคำแนะนำทั้งหมดก่อนใช้งาน  
เก็บคำแนะนำเหล่านี้เพื่อใช้ในอนาคต

## ผลิตภัณฑ์

- อย่าปิดกันหรือปิดซ่อนของรายการค้างด้านหลังเครื่อง
- ห้ามดันวัสดุใดๆ เข้าไปในเครื่องเพิ่มชั้นของรายการค้าง  
เพื่อจะง่ายต่อการดูแลล่างรายการสัมภาระชั้นด่วนที่ไฟฟ้าทำให้เกิดการลัดวงจร ส่งผลให้เกิดไฟไหม้ไฟฟ้าร้อน
- อย่าพยายามปิดไฟหลังพระราชทานทำให้เกิดความเสียหายได้ไม่ว่าชั้นส่วนใดๆ ในที่ที่สามารถซ่อนบ่รุงได้ด้วยตัวเอง โปรดใช้การบริการบ้านบุคลากรที่มีคุณสมบัติเหมาะสม
- ห้ามใช้ผ้าร้อนพับพับเพื่อหันหน้าออกในถักย้อมด้วยผ้าอ่อนๆ อาจทำให้หน้าจอดูร้อนรอย
- อย่ากระแทกหรือใช้แรงกดหน้าจอที่วิ่ง อาจทำให้หน้าจอที่วิ่งเสียหาย
- อย่ารุนแรง

## แหล่งจ่ายไฟและปลั๊ก

- ลดลงถ้าหากายได้เงื่อนไขต่อไปนี้:
  - หากไม่ได้ใช้งานทิวีปีนระยะเวลานาน
  - หากสายไฟหรือปลั๊กไฟเสียหาย
  - ทำความสะอาดที่ติดตั้งและปรับแต่งผลิตภัณฑ์ปั้นส่วนควบคุมที่ไม่ได้กล่าวไว้ในคู่มือการใช้งานนี้ เมื่อจากการปรับส่วนควบคุมอื่นๆ ที่ไม่เหมาะสมอาจส่งผลให้เกิดความเสียหายได้ หากเกิดเหตุการณ์นี้ขึ้น ให้ถอนปลั๊กและติดต่อศูนย์บริการ
  - หากมีการกระแทกหรือมีการตกหล่นที่ทำให้เครื่องเสียหาย

## สายไฟและสายสัญญาณ

- อย่าให้น้ำอะไรมากทันทีทันใดสายไฟและสายสัญญาณ
- ป้องกันสายไฟและสายสัญญาณถูกกัดทับ
- อย่าให้สายไฟหรือตัวเลือกไฟใช้ไฟมากเกินไป
- อย่าให้สายไฟและสายสัญญาณถูกความชื้น

## สภาพแวดล้อม

- อย่าวางชุดบนรถเข็น ชาตัง หรือโต๊ะที่ไม่มั่นคง
- วางชุดบนที่ระนาบจากภาคใต้ตั้ง
- ห้ามใช้ชุดใกล้บริเวณที่ชื้นและเย็น ยกเว้นชุดจากความร้อนสูงเกินไป เก็บชุดให้ห่างจากแสงแดดโดยตรง
- ห้ามใช้อุปกรณ์ใดๆ บนน้ำหนาดหรือกระเด็นใส่และห้ามใส่สิ่งของที่มีของเหลว เช่น แจ็กเก็ตวันน้ำ พันเกลือร่อง
- ห้ามใช้ชุดใกล้ที่มีสูญ

## ทำความสะอาด

- บีดผูนกเครื่องดูดการซื้อหัวจากด้วยผ้ามุ่นสะอาดหรือผ้าเช็ดทำความสะอาด
- อย่าใช้แรงมากเกินไปกับหน้าจอเมื่อทำความสะอาด
- ห้ามใช้น้ำหรือสารเคมีทำความสะอาดอื่นๆ ในการทำความสะอาดหน้าจอ เมื่อออกจากงานทำให้พื้นเดิมของทิวีปีนเสียหายได้หน้าจอ

## แนวทางที่วีนพนัง

**คำเตือน:** การดำเนินการนี้ต้องใช้คนสองคนเพื่อให้แน่ใจว่า การติดตั้งปลดล็อก ให้ปฏิบัติตามความปลอดภัยต่อไปนี้ หมายเหตุ:

- ตรวจสอบว่าทิวีและชุดติดผนังสามารถรับน้ำหนักที่วิ่งได้หรือไม่
- ปฏิบัติตามคำแนะนำในการติดตั้งที่ให้มาพร้อมกับพนัง
- ทิวีต้องติดตั้งครึ่งบนพนังในแนวตั้ง
- ตรวจสอบให้แน่ใจว่าใช้สกรูที่เหมาะสมกับวัสดุเท่านั้น
- ตรวจสอบให้แน่ใจว่าได้วางสายเคเบิลของเครื่องรับโทรทัศน์ไว้ในถักย้อมที่ไม่มีอันตรายจากการสะคัดล้ม
- คำแนะนำคือติดตั้งในแนวตั้งให้แน่นหนาทั้งหมดก่อนติดตั้งรับโทรทัศน์สามารถใช้ได้รวมกัน

## หมายเหตุ:

ภาพประกอบภายในเอกสารนี้มีไว้เพื่อการอ้างอิงเท่านั้น

## การเปิดเครื่อง

พำนາມคำแนะนำในหน้าหนึ่นเกี่ยวกับวิธีเปิดที่วิ่งและวิ่งในทุกตอนโทรลอก่อนที่จะไปปั๊งหน้าต่อไปที่อินบoks ใช้การตั้งค่าซ่อนสัญญาณโดยขั้นตอนนี้ดังนี้

- 1. ได้แบบทดสอบที่สอนในเรื่องโทรศัพท์

ข้อควรระวังในการใช้แบบทดสอบ:

- ใช้เฉพาะประเภทแบบทดสอบที่ระบุไว้เท่านั้น
- ตรวจสอบให้แน่ใจว่าคุณได้รับที่ถูกต้อง
- อ่านทดสอบอย่างละเอียดและพยายามทดสอบที่เขียนลง
- ห้ามใช้แบบทดสอบที่แบบชาร์จไฟได้
- อย่าใช้แบบทดสอบที่ความลึกมากเกินไป เช่น แสงแดด ไฟ หรือสิ่งที่คล้ายกัน
- เพราจะอาจเป็นสาเหตุให้ร้าวไฟฟ้าหรือระเบิดได้
- ออกแบบทดสอบที่ออกแบบมาสำหรับโทรศัพท์

- 2. เริ่มต้นต่อสายไฟเข้ากับโทรศัพท์ทันทีทันใด จากนั้นจึงต่อเข้ากับเตาผู้รับ

(หมายเหตุ: หากเชื่อมต่อสายไฟเข้ากับโทรศัพท์โดยเครื่อมต่อเฉพาะสายไฟเข้ากับเตาผู้รับหลัก)

- ทิ้งของคุณควรเชื่อมต่อ กับแหล่งจ่ายไฟ AC

ทิ้งของคุณควรเชื่อมต่อ กับแหล่งจ่ายไฟกระแสสลับ เท่านั้น ไม่ควรเชื่อมต่อไปปั๊งแหล่งจ่ายไฟกระแสตรง หากปลั๊กหลุดออกจากสายไฟ สิ่งที่ไม่ควรทำเป็นอย่างยิ่ง คือการเสียบปลั๊กเข้ากับเตาผู้รับหลัก เนื่องจากมีความเสี่ยงที่จะเกิดไฟฟ้าช็อตได้

- หากทิ้งของคุณเชื่อมต่อ กับแหล่งจ่ายไฟ DC

ทิ้งของคุณควรเชื่อมต่อ กับแหล่งจ่ายไฟ DC เท่านั้น จะต้องไม่มีเชื่อมต่อไปปั๊งแหล่งจ่ายไฟกระแสสลับ หากปลั๊กหลุดออกจากสายไฟเบิล อย่าทำนายให้ข้อใดข้อหนึ่งให้ต่อเข้ากับเตาผู้รับหลัก เนื่องจากมีความเสี่ยงที่จะเกิดไฟฟ้าช็อตได้

- 3. เริ่มต้นต่อสายจากภายนอกเข้ากับด้านหลังที่วิ่ง

- 4. เมื่อทำการเปิดเครื่อง ทิ้งจะเปิดอัตโนมัติหรืออัตโนมัติโดยอัตโนมัติ

(หมายเหตุ: สำหรับบางรุ่น การเปิดทิ้งต้องกดปุ่ม Power

ต้าไฟแสดงสถานะสว่างขึ้น ทิ้งจะชี้อยู่ในโหมดสแตนบายค.กดปุ่ม ๑ บนรีโมทคอนโทรลหรือคปุ่มที่ทิ้งเพื่อเปิดเครื่อง

## การปิดเครื่อง

- หากต้องการให้เครื่องทิ้งเข้าสู่โหมดสแตนบาย ให้กดปุ่ม ๑ บนรีโมทคอนโทรลของทิ้ง ทิ้งจะยังคงเปิดอยู่แต่มีการลื้นเปลืองพลังงานต่อ

- หากต้องการปิดเครื่องทิ้ง ให้กดปลั๊กไฟหลักออกจากเตาผู้รับหลัก

(หมายเหตุ: สำหรับบางรุ่น ให้กดปุ่มเปิด/ปิด เพื่อปิดเครื่องทิ้ง

## การเชื่อมต่อเครือข่าย

การเชื่อมต่อเครือข่ายในการเชื่อมอินเทอร์เน็ต คุณต้องสมัครบริการอินเทอร์เน็ตจากผู้ให้บริการอินเทอร์เน็ต

คุณสามารถเชื่อมต่อ กับเครือข่ายในบ้านได้ 2 วิธี:

- เติมสัญญาณไฟเบอร์ต่อ RJ45 (LAN) ที่แผงด้านหลัง
- เชื่อมต่อแบบ “ไร้สาย” โดยใช้เครือข่ายไร้สายของคุณ


หมายเหตุ: ฟังก์ชันนี้ไม่มีในบางรุ่น คำแนะนำด้านล่างเป็นเพียงวิธีปกติในการเชื่อมต่อทีวีไปยังเครือข่ายแบบใช้สายหรือไร้สาย วิธีการเชื่อมต่ออาจแตกต่างกันไปขึ้นอยู่กับเครือข่ายของคุณ การกำหนดค่า หากคุณมีข้อสงสัยเกี่ยวกับเครือข่ายในบ้านของคุณ โปรดติดต่อ ISP (ผู้ให้บริการอินเทอร์เน็ต) ของคุณ

## เชื่อมต่อ กับเครือข่ายแบบใช้สาย

ในการเชื่อมต่อ กับเครือข่ายแบบใช้สาย

1. ตรวจสอบให้แน่ใจว่า:

- คุณมีสายอีเธอร์เน็ตสายพ่อที่จะเชื่อมต่อทีวีของคุณ
  - เราเตอร์หรือไมค์เพิร์ฟอร์มมีพอร์ต Ethernet
  - การเชื่อมต่ออินเทอร์เน็ตความเร็วสูง
  - พอร์ต Ethernet (LAN) ที่ด้านหลังของทีวี
2. เชื่อมต่อสายเก็บอีเธอร์เน็ตของคุณเข้ากับเราเตอร์และเข้ากับพอร์ต Ethernet ที่ด้านหลังของทีวี
  3. ใช้การตั้งค่าเครือข่ายเพื่อกำหนดค่าทีวี




## เชื่อมต่อ กับเครือข่ายไร้สาย

การเชื่อมต่อ กับเครือข่ายไร้สาย

1. ตรวจสอบให้แน่ใจว่าคุณมี:

- เราเตอร์กระจายสัญญาณไร้สายความเร็วสูง
  - การเชื่อมต่ออินเทอร์เน็ตความเร็วสูง
  - อะแดปเตอร์ USB แบบ wireless
  - 2. ชุดทีวีพร้อมโมดูล Wi-Fi
  - 3. ไข้มุนคู่ห้ามเพื่อกำหนดค่าทีวี
- หมายเหตุ: บางรุ่นอาจมีโมดูลไร้สายภายในจึงไม่จำเป็นต้องใช้อแดปเตอร์ USB ไร้สาย บางรุ่นเดียวต่อร์ไร้สายภายนอกไม่สามารถใช้ร่วมกับทีวีได้



## การแก้ไขปัญหา

ปัญหานี้ในใหญ่ที่คุณพบในที่ว่าาเป็น "ได้แก้ไขได้โดย  
ราชการการแก้ไขปัญหาต่อไปนี้"

### ไม่วิภาวนามีเสียง

- ตรวจสอบว่าไฟวาร์บุรุกเกอร์ทำงานหรือไม่
- เชื่อมปลั๊กปุ่มไฟฟ้าอื่นเข้าบันไดรับ
- ตรวจสอบว่าทำงานหรือปิดอยู่
- ปลั๊กไฟสัมผัสนับตัวบันไดไม่ติด
- ตรวจสอบแหล่งเสียง

### ไม่มีเสียง

- เปลี่ยนระบบเสียง
- ปรับความอิ่มตัวของเสียง
- ลองซื้อเงิน อาจได้รับโปรแกรมขา-คำ

### รีโมทคอนโทรลไม่ทำงาน

- เปลี่ยนแบตเตอรี่
- ติดตั้งแบตเตอรี่ไม่ถูกต้อง
- ไม่ได้ต่อไฟหลัก

### ไม่วิภาวนามีเสียง

- ปรับความสว่างและความคมชัด
- ความล้มเหลวในการออกอากาศเกิดขึ้นได้

### ภาพปกติไม่มีเสียง

- กดปุ่ม Vol+ เพื่อเพิ่มระดับเสียง
- ระดับเสียงถูกตั้งค่าเป็นปีกเสียง กดปุ่มปีกเสียงเพื่อคืนค่าเสียง
- เปลี่ยนระบบเสียง
- อาจเกิดการรับสัญญาณของเสาอากาศ

สัญญาณเป็นคลื่นที่ไม่เป็นระเบียบหน้าจอ

มักเกิดจากการรบกวนในพื้นที่ เช่น รอดนต์ โภมไฟเดือไฟ และไดร์ฟาร์บุรุกเสาอากาศเป็นผลของการรบกวน

### หน้าจอไม่มีสัญญาณในโหมด VGA

ที่ว่าาไม่รู้วิธีความละเอียดที่ตั้งค่าไว้ใช้ แนะนำให้เปลี่ยนเป็นความละเอียดที่ต่ำสุดหรือความละเอียดอื่นๆ ตามมาตรฐานของระบบ Windows

เกิดจุดหรือการรบกวนของสัญญาณ  
หากเสาอากาศอยู่บริเวณห่างไกลจากสถานีโทรทัศน์ อาจเกิดสัญญาณอ่อน  
ซึ่งเป็นภาพมีรอยเปื้อนตามจุด เมื่อสัญญาณอ่อนมากอาจจำเป็นต้องติดตั้ง  
เสาอากาศพิเศษเพื่อปรับปรุงการรับสัญญาณ

- ปรับตำแหน่งและทิศทางเสาอากาศ
- ตรวจสอบการเชื่อมต่อของเสาอากาศ
- ปรับแต่งช่อง
- ลองเปลี่ยนช่องรับชม

### หน้าจอเมือง

มีจุดดำหรือเส้นแนวนอนประกายขึ้น หรือรูปภาพล่องลอยชั่วขณะก็เกิด  
จากการรบกวนจากระบบหลอดนีออน สาวนไฟฟ้า หรือเครื่องใช้ไฟฟ้า  
อื่นๆ

### ภาพชัด

ภาพชัดจากที่รับสัญญาณเข้ามาพร้อมกัน สามารถเปลี่ยนทิศทาง  
หรือตำแหน่งของเสาอากาศทำให้การรับสัญญาณดีขึ้น

### การรบกวนของกล้องความเร็วที่บุกบ้านนี้


ทำให้เกิดระยะลักษณะนี้หรือแนวเส้นร่อง และในบางกรณี  
การรบกวนเสียความเบร์ยังต่างในภาพทั้งหมด  
และลักษณะสัญญาณรบกวนทิศทาง

### ถ้าทิ่มชาร์ต

- กดปุ่ม Power เพื่อปิดทิ่มชาร์ต จากนั้นกดปุ่ม Power เพื่อตรวจสอบที่อีกครั้ง
- ลดดูอาทิไฟ จากนั้นกดปุ่มปีกปีกเพื่อเรียกทิ่มชาร์ตทิ่มชาร์ต หาก 2 วินาที  
ไม่สามารถแก้ไขได้โปรดติดต่อห้องการขายเพื่อแก้ไขปัญหา

### การติดตั้งขาทิ่มชาร์ต

หันด้านขาทิ่มชาร์ตในตรงตำแหน่งจากนั้นขันสกรูเพื่อขึ้นกับทิ่มชาร์ต  
หมายเหตุ: ภาพประกอบด้านล่างนี้ไว้เพื่อการอ้างอิงเท่านั้น  
และอาจแตกต่างจากรูปถ่ายที่ของคิดว่าจะทิ่มชาร์ต



# IMPORTANT SAFETY INSTRUCTIONS



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

## WARNING

1. To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel.
2. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.
3. Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
4. Please refer the information on exterior bottom enclosure for electrical and safety information before installing or operating the apparatus.
5. The mains plug/appliance couple is used as disconnect device, the disconnect device shall remain readily operable.
6. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
7. The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.
8. Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
  - Using cabinets or stands recommended by manufacturer of the television set.
  - Only using furniture that can safely support the television set.
  - Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and television set to a suitable support.
  - Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the television set or its controls. If your existing television set is being retained and located, the same considerations are above should be applied.
9. No naked flame sources, such as lighted candles, should be placed on the apparatus.
10. Keep a minimum distance of 5 cm around all edges of the display for sufficient ventilation.

### **Notes for battery disposal**

The batteries used with this product contain chemicals that are harmful to the environment. To preserve our environment, dispose of used batteries according to your local laws or regulations. Do not dispose of batteries with normal household waste. For more information, please contact the local authority or your retailer where you purchased the product. All trademarks are the property of their respective owners and all rights are acknowledged.



This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.



To prevent the spread of fire, keep candles or other open flames away from this product at all times.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

- \* Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
  - Using cabinets or stands recommended by manufacturer of the television set.
  - Only using furniture that can safely support the television set.
  - Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and television set to a suitable support.
  - Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the television set or its controls. If your existing television set is being retained and located, the same considerations are above should be applied.

# Table of Contents

---

## Chapter 1: Introduction

Precautions .....	11
Product .....	11
Power and Plug .....	11
Power Cord and Signal Cable .....	11
Use Environment .....	11
Cleaning .....	11
Hanging the TV Set on the Wall .....	11

## Chapter 2: General Operation

Switching on .....	12
Switching off .....	12
Network connection .....	13

## Chapter 3: Other Information

Troubleshooting .....	14
Base Installation .....	14

## Precautions

Read all of the instructions before operating the set.  
Keep these instructions well for future use.

### Product

- Do not block or cover the ventilation openings on the back cover.
- Do not push objects of any kind into this unit through the cabinet slots as they could touch the current carrying parts or short-circuit parts, resulting in fire, electric shock, or damage to the unit.
- Do not attempt to open the cabinet as this may cause damage. There are no parts inside you can service by yourself. Refer all servicing to qualified personnel.
- Do not touch the screen surface with fingers as this may scratch or mar the TV screen.
- Do not impact the TV screen with hard pressure as this may damage the TV screen severely.

### Power and Plug

- Unplug the set under the following conditions:
  - If the set will not be used for a long period of time.
  - If the power cord or the power outlet/plug is damaged.
  - Follow the instructions to install and adjust the product. Adjust those controls that are covered in this operating instructions as improper adjustment of other controls may result in damage. If this happens, unplug the set and refer to the service personnel.
  - If the set is subject to impact or has been dropped to have the cabinet damaged.

### Power Cord and Signal Cable

- Do not allow anything to rest on or roll over the power cord and the signal cable.
- Protect the power cord and the signal cable from being trampled.
- Do not overload the power cord or the power outlet.
- Do not expose the power cord and the signal cable to moisture.

### Use Environment

- Do not place the set on an unstable cart, stand, or table.
- Place the set on a place that allows good ventilation.
- Do not use the set near damp, and cold areas. Protect the set from overheating.
- Keep the set away from direct sunlight.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Do not use the set near dust place.

### Cleaning

- Dust the set by wiping the screen and the cabinet with a soft, clean cloth or some special liquid cleaner.
- Do not apply excessive force to the screen when cleaning.
- Do not use water or other chemical cleaner to clean the screen as this may damage the surface of the TV screen.

### Hanging the TV Set on the Wall

#### Warning: This operation requires two people.

To ensure a safe installation, observe the following safety notes:

- Check that the wall can support the weight of the TV set and wall mount assembly.
- Follow the mounting instructions provided with the wall mount.
- The TV set must be installed on a vertical wall.
- Make sure to use only screws suitable for the material of the wall.
- Make sure that the TV set cables are placed so that there is not danger of tripping over them.

All other safety instructions about our TV sets are also applicable here.

**Note:** *Illustrations within this publication are provided for reference only.*

## Switching on

Follow the instructions on this page on how to switch on your TV set and the remote control before going on to following pages describing how to use the channel set-up procedure.

1. Insert two batteries in the remote control.

Precautions on using batteries:

- Only use the battery types specified.
- Make sure you use the correct polarity.
- Do not mix new and used batteries.
- Do not use rechargeable batteries.
- Do not expose batteries to excessive heat such as sunshine, fire or the like, throw them in a fire, recharge them or try to open them, as this could cause them to leak or explode.
- Remove the batteries from the remote control if you are not using it for a long period of time.

2. Connect the power cable **FIRST** to the television, **THEN** to a mains socket.

(Note: If the power cable is connected to the television, please only connect the power cable to the mains socket.)

- If your TV is connected to an AC supply  
Your TV set should only be connected to an AC supply. It must not be connected to a DC supply. If the plug is detached from the cable, do not, under any circumstances, connect it to a mains socket, as there is a risk of electric shock.
- If your TV is connected to a DC supply  
Your TV set should only be connected to a DC supply. It must not be connected to a AC supply. If the plug is detached from the cable, do not, under any circumstances, connect it to a mains socket, as there is a risk of electric shock.

3. Connect an outside aerial to the **ANTENNA IN** socket at the back of the TV set.

4. When powered on, the TV will be turned on directly or be in standby.

Note: For some models, switch the TV on by pressing the power button.

If the power indicator lights up, the TV set is in standby mode. Press the  $\odot$  button on the remote control or on the TV set to turn on the TV.

## Switching off

- To put the TV set into standby mode, press the  $\odot$  button on the remote control or on the TV, the TV set remains powered up, but with low energy consumption.
- To switch off the TV set, unplug the mains socket from the mains outlet.  
Note: For some models, press the power button to switch off the TV set .

## Network Connection

To access the internet, you must subscribe high speed broadband internet service from your internet service provider.

Your TV can be connected to your home network in two ways:


- Wired, using the RJ45 (LAN) connector on the back panel.
- Wireless, using the internal wireless or external wireless USB adapter and your home wireless network.

**Note:** This function is not available for certain models. Instructions below are just the usual ways to connect your TV to the wired or wireless network. The connection method may be different depending on your actual network configuration. If you have any questions about your home network, please refer to your ISP (Internet Service Provider).

### Connecting to a wired network

To connect to a wired network:


1. Ensure you have:
  - An ethernet cable long enough to reach your TV
  - A router or modem with an available Ethernet port
  - A high-speed internet connection
  - An Ethernet (LAN) port on the back of the TV
2. Connect your ethernet cable to the router and to the Ethernet port on the back of the TV.
3. Use the Network Settings to configure the TV.



### Connecting to a wireless network

To connect to a wireless network:

1. Ensure you have:
  - A router broadcasting a high-speed wireless signal
  - A high-speed internet connection
  - A wireless USB Adapter (not need for a built-in wireless connection).
2. The TV set with Wi-Fi Module.
3. Use the Network menu to configure the TV.



**Note:** Some models may have internal wireless module, then the wireless USB adapter is unnecessary. Some external wireless adapters cannot be compatible with the TV.

## Troubleshooting

Most problems you encounter with your TV can be corrected by consulting the following troubleshooting list.

### No picture, no sound

1. Check if the fuse or circuit breaker is working.
2. Plug another electrical device into the outlet to make sure it is working or turned on.
3. Power plug is in a bad contact with the outlet.
4. Check the signal source.

### No color

1. Change the color system.
2. Adjust the saturation.
3. Try another channel. Black-white program may be received.

### Remote control does not work

1. Change the batteries.
2. Batteries are not installed correctly.
3. Main power is not connected.

### No picture, normal sound

1. Adjust the brightness and contrast.
2. Broadcasting failure may happen.

### Normal picture, no sound

1. Press the **Vol+** button to increase volume.
2. Volume is set to mute, press the mute button to restore sound.
3. Change the sound system.
4. Broadcasting failure may happen.

### Unorderly ripples on the picture

It is usually caused by local interference, such as cars, daylight lamps and hair dryers. Adjust the antenna to minimize the interference.

### Blank screen in VGA mode

Perhaps the TV can not recognize the resolution set by the PC. Suggest to change to the best resolution or other standard resolutions of the Windows system.

### Snowy dots and interference

If the antenna is located in the fringe area of a television signal where the signal is weak, the picture may be marred by dots. When the signal is extremely weak, it may be necessary to install a special antenna to improve the reception.

1. Adjust the position and orientation of the indoor/outdoor antenna.
2. Check the connection of antenna.
3. Fine tune the channel.
4. Try another channel. Broadcasting failure may happen.

### Ignition

Black spots or horizontal streaks appear, or the picture flutters or drifts. This is usually caused by interference from car ignition system, neon lamps, electric drills, or other electrical appliance.

### Ghost

Ghosts are caused by the television signal following two paths. One is the direct path, the other is reflected from tall buildings, hills, or other objects. Changing the direction or position of the antenna may improve the reception.

### Radio frequency interference

This interference produces moving ripples or diagonal streaks, and in some case, loss of contrast in the picture. Find out and remove the radio interference source.

### If the TV is crashed


1. Press the **Power** button to turn off TV, then press the **Power** button again to reset TV.
2. Unplug the power cord, then press the **Power** button to reset TV.

*Note: If these 2 methods can not be resolved, please contact the after-sales to solve.*

## Base Installation

To fix the double support base on the unit by screws, the installation is completed.

*Note: Illustrations below are provided for reference only and may differ from actual product appearance.*



# Aconatic


บริษัท ไฮไฟ ออเรียนต์ ไทย จำกัด (มหาชน)  
HIFI ORIENT THAI PUBLIC COMPANY LIMITED

83/161-1-162 ซอยงามวงศ์วาน 47(ชั้นเดียว) โทร. 0-2954-5281, 0-2580-6955

แขวงจุ่งจอมทัช เขตห้วยขวาง

Core Line. 02-591-9444, 02-589-5115

กรุงเทพมหานคร 10210



หมายเหตุ : บริษัทขอสงวนสิทธิ์ในการเปลี่ยนแปลงรายการของสินค้าโดยไม่ต้องแจ้งให้ทราบล่วงหน้า