

ACONATIC

คู่มือการใช้งาน
เตาปิ้งย่างอเนกประสงค์

รุ่น AN-PSG1540

โปรดอ่านคู่มืออย่างละเอียดก่อนใช้งาน



คำเตือน : พื้นผิวของเครื่องอาจร้อนในขณะที่ใช้งาน

เครื่องใช้ไฟฟ้านี้สามารถใช้งานได้โดยเด็กอายุ 8 ปีขึ้นไปและบุคคลที่มีความบกพร่องทางกายภาพ ประสาทสัมผัส หรือจิตใจ ควรได้รับการดูแลอย่างใกล้ชิด

ข้อควรระวังด้านความปลอดภัย

1. โปรดอ่านคำแนะนำนี้ก่อนใช้งาน
2. เก็บเครื่องให้ห่างจากมือเด็ก
3. ขณะใช้งาน อย่าทิ้งเครื่องไว้โดยไม่มีผู้ดูแล
4. ห้ามสัมผัสเครื่องระหว่างใช้งานหรือหลังใช้งานด้วยมือเปล่า ให้ใช้ถุงมือ ป้องกันความร้อน ผ้า หรือใช้คีมจับที่มีมาให้กับตัวเครื่อง
5. โปรดถอดปลั๊กทุกครั้งก่อนทำความสะอาด และห้ามนำเครื่อง ปลั๊ก หรือสายไฟแช่งลงในน้ำ
6. ก่อนจัดเก็บหรือทำความสะอาด ควรปล่อยให้เครื่องเย็นก่อนทุกครั้ง
7. ตรวจสอบให้แน่ใจว่าวางถาดไว้ตรงตำแหน่งการใช้งานทุกครั้ง และนำถาดออก ก่อนจัดเก็บทุกครั้ง
8. เก็บคู่มือการใช้งานไว้ในที่ปลอดภัยสำหรับการใช้งานหรืออ้างอิงการใช้งานในอนาคต
9. หากตัวเครื่องหรืออุปกรณ์เสียหายให้ปรึกษาศูนย์ซ่อมหรือผู้จัดจำหน่าย
10. อุปกรณ์นี้ไม่ได้มีวัตถุประสงค์ไว้ใช้งานสำหรับโดยบุคคลที่ด้อยความสามารถทางร่างกายประสาทสัมผัสหรือจิตใจ รวมถึงเด็กหรือผู้ที่ขาดประสบการณ์และความรู้ เว้นแต่ว่าจะได้รับการดูแลหรือการสอนเกี่ยวกับการใช้เครื่องใช้ไฟฟ้าโดยบุคคลที่รับผิดชอบด้านการดูแลของบุคคลเหล่านั้น
11. ควรดูแลเด็กเพื่อให้แน่ใจว่าจะไม่เล่นกับเครื่อง
12. เครื่องนี้ไม่ได้ออกแบบให้ทำงานแบบตั้งเวลาภายนอกหรือระบบควบคุมระยะไกล

วิธีการทำให้เตาของคุณทำงานได้ดีที่สุด

เตาจะถูกออกแบบมาให้ทำอาหารโดยใช้น้ำมันและไขมันธรรมชาติที่อยู่ในอาหารเท่านั้น และไม่จำเป็นต้องเพิ่มไขมันเพิ่มเติม ในระหว่างการทำอาหาร ไขมันส่วนมากในอาหารจะถูกกำจัดออกและจะถูกรวบรวมไว้ในถาดรอง ซึ่งทำให้อาหารมีสุขภาพดีว่าการทอดหรือย่างโดยใช้น้ำมันหรือใช้ไขมันเพิ่มเติม

คำแนะนำการใช้งาน

1. ก่อนการใช้งานครั้งแรกหรือหลังจากไม่ได้ใช้งานเป็นเวลานาน ใช้ผ้าชุบน้ำที่บิดหมาดๆ ในการทำความสะอาดพื้นผิว
2. เพื่อการทำอาหารที่ดีที่สุด ให้เสียบปลั๊กและเปิดเตาอย่างล່วงหน้าสามถึงสี่นาทีก่อนใช้งาน และปิดฝาโดยไม่มีอาหารอยู่ภายใน
3. เปิดฝาดูออกโดยใช้ถุงมือป้องกันความร้อน หรือผ้า และระมัดระวังเมื่อนำอาหารลงบนเตาปิ้งย่าง
4. โปรดปิดฝาดูอย่างระมัดระวัง ไฟแสดงสถานะจะสว่างขึ้นเพื่อบอกว่าเครื่องกำลังทำงาน
5. ก่อนทำอาหารทุกครั้งโปรดตรวจสอบวิธีการทำอาหาร เพื่อให้แน่ใจว่าจะทำออกมาถูกต้อง
6. เมื่ออาหารสุกให้นำอาหารออกจากเตาปิ้งโดยใช้อุปกรณ์หรือไม้พายที่เหมาะสม
7. หลังจากการใช้งาน ให้ถอดปลั๊กทุกครั้ง และปล่อยให้เครื่องเย็นตัวลงก่อนที่จะทำความสะอาดและทำการจัดเก็บ โดยก่อนทำการจัดเก็บ ให้ตรวจสอบว่าได้นำถาดออกมาทำความสะอาดแล้ว

คำแนะนำในการทำความสะดวก

1. ตรวจสอบให้มั่นใจว่าเครื่องถูกถอดปลั๊กและเย็นลงแล้วก่อนที่จะทำความสะอาด
2. ห้ามใช้แผ่นขัดหรือสารทำความสะอาดที่มีฤทธิ์กัดกร่อนอาจทำให้เครื่องเสียหายได้
3. สามารถใช้น้ำอุ่น ทำความสะดวกตัวถาดได้
4. ใช้อุปกรณ์หรือไม้พายเพื่อชูดเศษอาหารออก และสามารถใช้ฟองน้ำหรือทิชชูเปียกเพื่อนำเศษอาหารที่ติดออก
5. บริเวณตัวเครื่องสามารถทำความสะอาดด้วยกระดาษทิชชูหรือผ้าสะอาด

ACONATIC

OPERATING INSTRUCTION

GRILL

MODEL AN-PSG1540

Please read the manual carefully before use.



(CAUTION: Hot surface): The surfaces are liable to get hot during use.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised. Keep the appliance and its cord out of reach of children less than 8 years.

Basic Safety Instructions

- 1. Read and familiarize yourself with all operating instructions before attempting to use the grill.**
- 2. Keep the appliance out of the reach of children.**
- 3. As all cooking times vary do not leave the appliance unattended while switched on.**
- 4. Beware that surfaces may become very hot during and after use always use an oven glove or clothe. Use the handles provided and do not touch heating surfaces.**
- 5. Always disconnect the plug from the mains before cleaning--- wipe clean only --do not immerse unit, plug or cord in water.**
- 6. Always allow the unit to cool down before storage or cleaning.**
- 7. Always ensure that the plastic drip tray is in place before use, remove and empty the drip tray before storing the unit.**
- 8. Always retain user instructions safely for future use and reference.**
- 9. There are no user serviceable parts, if the unit fails, consult a qualified electrical repair center or contact the supplier.**
- 10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**
- 11. Children should be supervised to ensure that they do not play with the appliance.**
- 12. This appliance is not intended to be operated by means of an external timer or separate remote-control system.**

Getting The Best Results From Your No Fat Grill

The grill is designed to cook using only the natural oils and fats contained within the food-no extra fat has to be added.

During cooking much of the fat contained within the food is removed and will be collected in the drip tray thus making the food more healthy than if fried or grilled using additional oils or fats.

Best results are therefore obtained when cooking foods containing some natural fats e.g. all types of meat and fish, burgers and other meat products, however different types of food can also be cooked including vegetables and even sandwiches.

Operating Instructions

- 1. Before first use or after long periods of non-use wipe the non-stick cooking plates with a damp cloth to ensure clean surfaces.**
- 2. For best results always pre-heat the grill for three to four minutes before use by plugging in to the mains and allowing it to heat up whilst closed, without any food inside.**
- 3. Open the lid using an oven glove or cloth, ensure it engages into the upright position, and carefully position the food to be cooked onto the bottom plate.**
- 4. Carefully close the lid, the power light will glow to indicate the grill is in use.**
- 5. Check regularly to see how the food is cooking, it is not necessary to turn the food as it cooks from both top and bottom plate.**
- 6. When the food is fully cooked remove it carefully from the grill using specially shaped spatula or plastic/wood tools suitable for non-stick surfaces.**
- 7. Immediately after use unplug the grill and allow it to cool sufficiently before cleaning and storage, always ensure that the drip tray is removed and cleaned.**

Cleaning Instructions

- 1. Ensure that the unit is unplugged and cool before attempting cleaning.**
- 2. Never use a scouring pad or abrasive cleaner as this will damage both plastic and metal parts.**
- 3. The drip tray may be washed in hot soapy water.**
- 4. Use specially shaped spatula or plastic/wood tools to scrape off any excess food adhering to the non-stick plates, a wet non-abrasive sponge or paper towel can be used to rub off stubborn patches.**
- 5. Dry the non-stick plates thoroughly using a paper towel, the outer plastic case can be cleaned with a paper towel or soft cloth.**

บริษัท ไฮไฟ โอเรียนท์ ไทย จำกัด (มหาชน)
HIFI ORIENT THAI PUBLIC COMPANY LIMITED

83/161-162 ซอยงามวงศ์วาน47(ชั้นเขต2) โทร. 0-2954-5281 , 0-2580-6955
แขวงทุ่งสองห้อง เขตหลักสี่ Core Line. 02-591-9444 , 02-589-5115
กรุงเทพมหานคร 10210



หมายเหตุ : บริษัทขอสงวนสิทธิ์ในการเปลี่ยนแปลงรายการของสินค้าคุณและรายละเอียดสินค้าโดยมีคั้งแจ้งให้ทราบล่วงหน้า