


คู่มือการใช้งาน

ACONATIC

รุ่น AN-TV55100M

วิดีโอการติดตั้ง
AN-TV55100M



หมายเหตุ: ตรวจสอบผลิตภัณฑ์ รวมถึงอุปกรณ์กับรูปลักษณะจริงของผลิตภัณฑ์ที่ได้รับ ก่อนทำการติดตั้ง



ก่อนการติดตั้ง โปรดตรวจสอบให้แน่ใจว่าติดตั้ง ขนาด และน้ำหนักทีวีของคุณ ตรงตามข้อกำหนด หากมีข้อสงสัยเกี่ยวกับคำแนะนำและคำเตือน โปรดติดต่อเราเพื่อขอความช่วยเหลือ


ข้อสำคัญ:

- เมื่อติดตั้งซ้ำ ผู้เชี่ยวชาญควรใช้อุปกรณ์และเครื่องมือเพื่อความปลอดภัย การประกอบ การติดตั้งที่ไม่ถูกต้องอาจทำให้ทีวีหล่นหรือได้รับบาดเจ็บสาหัสได้
- ก่อนการติดตั้ง โปรดตรวจสอบให้แน่ใจว่าพื้นผิวสามารถรองรับน้ำหนักอุปกรณ์ และอุปกรณ์เสริมทั้งหมดได้อย่างปลอดภัย
- โปรดอย่าติดตั้งเกินความสามารถในการรับน้ำหนักที่กำหนดไว้ มิฉะนั้น อาจทำให้เกิดการบาดเจ็บสาหัสหรือทรัพย์สินเสียหายได้
- ผลิตภัณฑ์นี้มีชิ้นส่วนที่มีขนาดเล็ก หากกลืนเข้าไปอาจมีความเสี่ยงต่อระบบหายใจได้ และควรเก็บให้พ้นมือเด็ก
- ผลิตภัณฑ์นี้เหมาะสำหรับใช้ภายในอาคารเท่านั้น และอาจทำให้ผลิตภัณฑ์เสียหายและเสี่ยงต่อการบาดเจ็บ

การซ่อมบำรุง:


โปรดตรวจสอบการเชื่อมต่อระหว่างตัวยึดและทีวีด้วยตนเองเป็นระยะๆ ว่ามั่นคงดีหรือไม่ และตรวจสอบสกรูที่อาจหลุดออก เนื่องจากใช้งานเป็นเวลานาน (อย่างน้อยทุก 3 เดือน) หากพบอุปกรณ์ชำรุด โปรดเปลี่ยนอุปกรณ์ หรือ ติดต่อ ศูนย์บริการ

1. การติดตั้ง ล้อ ที่ฐาน




2. การติดตั้ง ชุดขาตั้ง ที่ฐาน

ขันให้แน่นด้วยประแจ L (I)




หมายเหตุ: เมื่อติดตั้งฐาน ให้ใช้แหวนรอง D8 ในการติดตั้ง

3. การติดตั้ง ถาดรอง อุปกรณ์




หมายเหตุ: เมื่อติดตั้งฐาน ให้ใช้แหวนรอง D8 ในการติดตั้ง


4. การติดตั้ง แผ่นยึด




7. แขนทวิบรินแผ่นยึด



5. การติดตั้ง แผ่นเสริม สำหรับ ติดตั้งอุปกรณ์ ต่างๆ




9. ติดตั้งเสร็จสมบูรณ์



อุปกรณ์ที่มีภายในกล่อง (ก่อนการติดตั้งโปรดตรวจสอบให้แน่ใจว่าชิ้นส่วนต่างๆ ครบถ้วน หากมีชิ้นส่วนใดหายไปหรือเสียหาย โปรดติดต่อศูนย์บริการ)

ลำดับ	รายการ	
A	ประแจปากแบน 1 ชิ้น	บูชรองน็อต 4 ชิ้น
B	สกรูหกเหลี่ยม M8 x 70 mm 4 ชิ้น	สกรู M8 x 25 mm 4 ชิ้น
C	สกรู M8 x 40 mm 12 ชิ้น	สกรู M6 x 25 mm 4 ชิ้น
D	สกรู M8 x 70 mm 4 ชิ้น	
E	สกรู M5 x 10 mm 4 ชิ้น	
	สกรู M6 x 10 mm 2 ชิ้น	
F	สกรู M6 x 60 mm 2 ชิ้น	
G	แหวนรอง D8 24 ชิ้น	
	แหวนรอง D6 6 ชิ้น	
H	น็อต D8 12 ชิ้น	
I	ประแจ L 1 ชิ้น	

6. ติดตั้งขาแขวนทีวี




Installation Manual

ACONATIC

Model AN-TV55100M

วิธีติดตั้ง
AN-TV55100M



Note: This manual is a universal version (divided into complete and palletless versions), and the appearance is based on the actual appearance of the product received. This installation step is a complete version installation step. If there is no upper tray version installed, skip the upper tray installation step.



Before installation, please ensure that the installation holes, dimensions, and standard weight of your TV frame meet the specifications and standards of the TV frame. If you have any questions or ambiguities about the instructions and warnings, please contact us for assistance.


⚠ Important:

1. When installing the bracket, professional personnel should use safety devices and tools according to the assembly manual. Incorrect installation may cause the TV to fall or serious personal injury.
2. Before installation, please ensure that the support surface can safely support the weight of the equipment and all accessories.
3. Please do not exceed the marked load capacity, otherwise it may cause serious injury or property damage.
4. This product contains small components. If swallowed, it can pose a risk of breathing and should be kept out of reach of children.
5. This product is only suitable for indoor use and may cause damage to the product and risk personal injury when used outdoors


Maintenance:

Please manually check the connection between the bracket and the TV at regular intervals for stability and any screws that may fall off due to prolonged use (at least every three months). If there are safety hazards, please replace the accessories or reinforce the installation in a timely manner.

1. Installation of four wheels on the base




2. Installation of columns and bases




Note: When installing the base, use D8 gaskets for installation.

3. Installation of pallets




Note: When installing the base, use D8 gaskets for installation.


4. Installation of panels




6. Hang the TV on the panel




5. Installation of upper tray



8. Installation completed



7. Installation of hooks



Install components

(Before installation, be sure to check if the components are complete. If there are any missing or damaged parts, please contact your supplier.)

NO	Bracket installation accessories	
A	Open end wrench * 1	Elevating pad * 4
B	M8 * 70 external hexagonal screw * 4	M8 * 25 pan head screw * 4
C	M8 * 40 hex socket screw * 12	M6 * 25 pan head screw * 4
D	M8 * 70 hex socket screw * 4	
E	M5 * 10 countersunk head screw * 4	
	M6 * 10 Phillips screw * 2	
F	M6 * 60 Phillips screw * 2	
G	D8 gasket * 24	
	D6 gasket * 6	
H	D8 nut * 12	
I	Internal hexagonal wrench * 1	